

# Distribution Box

## Part no. ICS-1-DB-0/2

The distribution box enables the laser interlock operator cable to connect between the laser and the laser safety interlock control system. The distribution box is normally wall mounted.

The ICS-1-DB-0-2 has two shutter connections.



**lasermet**  
laser safety solutions