

# Distribution Box

## Part no. ICS-1-DB-4-0

The distribution box enables the laser interlock operator cable to connect between the laser and the laser safety interlock control system. The distribution box is normally wall mounted.

The ICS-1-DB-4-0 has four interlock operator connections.

