

Interlock Override Push Button

Part no. PUSH-BUT, PUSH-BUT-FM

The Interlock Override is a push button that is wired into the interlock control system.

When the button is pressed, the door switches and any mag-locks are overridden allowing the door to be opened without switching off the laser.

After a short period of time - for example, 20 seconds - the laser will be isolated and effectively switched off if the door has not been closed. If this occurs, the laser must be re-armed by the interlock.



PUSH-BUT

The unit measures 72mm wide x 76mm high x 65mm deep (75mm deep including the button)



PUSH-BUT-FM

An alternative Flushmount version is also available. It has the same functionality.

lasermet
laser safety solutions*